Folding Bench

White plastic folding bench for 4 persons – folds in half like a suitcase



Folding bench, 180 cm

A folding bench for 4 persons with a steel frame and a seat made of UV-stabilised HDPE plastic with an anti-slip surface. It folds in half to 90 cm and can be carried like a suitcase. Ideal for weddings, garden parties, markets and catering.

Length	180 cm open / 90 cm folded
Width	30 cm
Height	45 cm
Capacity	4 persons, max. 300 kg in total
Frame	steel
Seat	UV-stabilised HDPE plastic, white, anti-slip

Package contents

- 1 folding bench, fully assembled – no tools needed

Unfolding, folding and use

1. **Open the bench**
   Lay the folded bench on its side. Open the catch and unfold both halves to the full length of 180 cm.
2. **Unfold the legs**
   Fold out both pairs of legs until they are fully upright. Slide the locking rings over the leg joints so the legs cannot fold in.
3. **Lock the middle**
   Make sure the middle joint is fully straight and locked so the bench cannot fold in the middle.
4. **Turn and check**
   Turn the bench onto its legs. Check that it stands firmly and level and that all locks are closed.
5. **Fold**
   Turn the bench over, slide back the locking rings, fold in the legs and fold the bench in half. Close the catch and carry it by the handle.

Note: The exact locking mechanism may vary slightly between production batches. Always check that the legs and the middle joint are fully locked before use.



Folded in half with carrying handle



Bench with a folding table

⚠ Safety instructions

For this product

- Maximum 4 persons and 300 kg in total. Distribute the load evenly – do not let all persons sit on one end.
- Do not stand, jump or dance on the bench and do not use it as a ladder or table for heavy objects.
- Make sure all leg locks and the middle lock are fully engaged before use.
- Sit down and stand up carefully – a heavily unbalanced load on one end can tip the bench.
- Risk of pinching: keep fingers away from the joints and locks when folding and unfolding.

General

- Use only on a firm, level and dry surface. Do not use on soft, uneven or slippery ground.
- Before every use, check the frame, joints, rivets and plastic parts. Do not use damaged or deformed furniture.
- Keep children away when folding and unfolding, and do not let them play with the furniture.
- Keep away from open fire, grills, heaters and other heat sources.
- Secure the furniture in strong wind – folded or light furniture can be blown away.

Care and storage

- Clean with water and mild soap. Do not use solvents or abrasive cleaners.
- Let the bench dry before folding and storing it.
- Store in a dry place. Although the plastic is UV-stabilised, long storage in direct sunlight is not recommended.

The manufacturer is not liable for damage or injury caused by overloading, improper use, use on unsuitable ground or by not following these instructions.